



# KE EMU CRANE


## — set up options




**KE Emu Crane** Parts required (10m set-up)  
Centre coupling.  
Segments 1, 2, 3, 4 and head end, weight end and weight extension.  
Large spreaders. Small spreaders.  
Two x 10m spreader cable sets.  
Two x 10m leveling cables.




**KE Emu Crane** Parts required (8m set-up)  
Centre coupling.  
Segments 1, 2, 4 and head end, weight end and weight extension.  
Large spreaders.  
Two x 8m spreader cables.  
Two x 8m leveling cables.



**KE Emu Crane** Parts required (6m set-up)  
Centre coupling.  
Segments 1, 2 and head end. Weight end.  
Small spreaders.  
Two x 6m spreader cables.  
Two x 6m leveling cables.



**KE Emu Crane** Parts required (4m set-up)  
Centre coupling.  
Segments 1 and head end. Weight end.  
Small spreaders.  
Two x 4m spreader cables.  
Two x 4m leveling cables.



**KE Emu Crane** Parts required (2m set-up)  
Centre coupling.  
Head end. Weight end.  
Two x 2m leveling cables.

